# V-Carving Tutorial (V-Carve Almost Anything Using F-Engrave Image Mode)



To successfully use this tutorial F-Engrave and Potrace need to be installed and working. Help installing these programs is available at: <u>F-Engrave Setup</u>

# Step 1. Select an image to v-carve.

Any image that is black and white or that you can convert to black and white.

#### Step 2. Convert the image to a format that F-Engrave can import.

Assuming Potrace is installed and working properly the image types that can be imported are: BMP (Windows Bitmap), PBM (Portable Bitmap), PGM (Portable Graymap) and PPM (Portable Pixmap).

The input image should be converted to black and white using any image editing software. If pixel values other than black and white appear in the input, they will be converted to black and white within F-Engrave (Potrace actually does the work). Color or grayscale picture will produce a result but the internal conversion does not allow you to preview the true input. (additionally the size of true black and white images is dramatically smaller than grayscale and color images.)

### Step 3. Import the image into F-Engrave

3a. Open F-Engrave

- Windows: Double click the **f-engrave-xx.exe** file (where xx is the version number)
- Linux: Type python f-engrave-xx.py at a command prompt
- 3b. Change the mode to image [ Settings Image Mode ]

😤 f-engrave-0.9.py by Scorch							
File Edit View	Settings Help						
Text Font Propert	General Settings			Gcode Properties:			
Text Height	Ritman Import Settings			Feed Rate	5.0	in/min	
Line Thickness				Z Safe	0.25	in	
Text Width	<ul> <li>Engrave Mode</li> <li>V-Carve Mode</li> </ul>			Cut Depth	-0.005	in	
Char Spacing	✓ Text-Mode (CXE/TTE)			Font Files:			
Word Spacing	Image Mode (DXF/Bitmap)	<b>3</b> b.		LiberationMono-B	old.ttf	<b></b>	
Line Spacing	1.1			LiberationMono-B	oldItalic.ttf		
Text Position and Orientation:       Image: Constraint of the second secon							

3c. Open your image file by selecting [ File - Open DXF/Bitmap File ] then use the file open dialog to navigate to and select an image file.

f-engrave-0.9.p	y by Scorch									<b>x</b>
File Edit View	Settings	Help								
Open F-engrave G-Code File Gcode Pr							Gcode Properties	perties:		
Save G-Code F	nap File ile		с.					Feed Rate	5.0	in/min
Save SVG File								Z Safe	0.25	in
Exit								Cut Depth	-0.005	in
Char Spacing	25	%						Font Files:		
Word Spacing	100	%						LiberationMono-	Bold.ttf	•
Line Spacing	1.1							LiberationMono-	BoldItalic.ttf	
Text Position and	l Orientation		F-	En	gr	7 B (	Vê	LiberationMono- LiberationMono- LiberationSans-B LiberationSans-B	Italic.ttf Regular.ttf old.ttf oldItalic.ttf	

#### Step 4. Change the main window settings to set the output size and cut method.

4a. Adjust the size of the image. This is accomplished by changing the **Image height** property. The resulting image size is displayed in the status bar.

4b. Change the **Feed Rate** and **Z Safe** values to values that are suitable for your machine and material. The defaults are pretty safe for most operations (when using English units) increasing the **Feed Rate** and decreasing the **Z Safe** can help improve the speed of the carving process. (for V-Carving the **Cut Depth** is determined by the v-bit geometry, which will be set later, so there is no need to change this value unless you are using engrave mode)

4c. Since we will be v-carving, select V-Carve mode at the bottom of the window.

4d. The **Origin** option can be modified to change the zero position of the g-code output if desired. The current position of the origin is displayed on the preview window by red and blue lines (shown in the lower left in the image below).

4e. After changing settings on the main screen click the **Recalculate** button to update the display.



### Step 5. Change the V-Carve Settings

5a. Open the V-Carve Settings window [ Settings - V-Carve Settings ]



5b. Set the **V-Bit Angle** and **V-Bit Diameter** to match your cutting bit. The V-Bit Diameter can be set to diameters less than the actual cutting bit diameter to limit the depth of v-carving.



# Step 6. Execute V-Carve Calculation

6a. All of the necessary settings have been changed. Executed the V-Carve calculation by clicking the **Calculate V-Carve** button on the v-carve settings window.

As the calculation is performed the display will update and a status window will give an estimate of the time remaining. When the calculation is complete the blue areas will be replaced by black and the tool paths will be shown as white lines. This process can take a long time for complex designs.

P Executing V-Carve								
Stop Calculation 1.8 % ( 4.7 Minutes Remaining   4.8 Minutes Total )								
f-engrave-0.9.py	y by Scorch							
File Edit View	Settings Hel	lp						
Image Properties:								
Image Height	5 ir	n						
Line Thickness	0.01 in	n		0.81007				
Image Width	100 %	6			The last			
Image Position ar	nd Orientation:		(hele)	Ru) <i>(6</i> 8	DAL			
Image Angle	0.0 d	eg 🖉	S 2 2					
Origin	Default	_		<b>E</b> NE SCË				
Flip Image		1 States	EMR -					
Mirror Image			<i>13/1</i> /2003					
Gcode Properties:	:							
Feed Rate	50 in	n/min		EA & SSA !				
Z Safe	.04 in	n [		VL'MZ^ V				
Cut Depth	-0.005 in	1						
Polski_Crest.bmp		—	- EFAQ	<u> </u>	SS <sup>®</sup>			
			<u>v</u>					
	C Engrave • V-Carve			~				
Recalculate	Calc V-Carv	ve		$\bigvee$				
16.1 % ( 4.0 Minutes Remaining   4.7 Minutes Total )								

### Step 7. Review the Results

The areas that will be touched by the v-bit are shown in black and the tool paths are shown in white. As seen in the screenshot some areas of the image have no been carved. These regions can be cleaned up using the cleanup section of the V-Carve Settings window.

T-engrave-0.9.py by Scorch						
File Edit View Settings Help						
Image Properties: Image Height 5 in						
Line Thickness 0.01 in Image Width 100 %						
Image Position and Orientation:						
Origin Default						
Flip Image						
Mirror Image						
Gcode Properties:						
Feed Rate 50 in/min						
Z Safe .04 in						
Cut Depth -0.005 in						
Polski_Crest.bmp						
C Engrave						
© V-Carve						
Recalculate Calc V-Carve						
V-Carve Calculations 100% Complete						

# Step 8. Clean Up Settings

8a. Set the **Cleanup Search Distance**. This setting determines how far away from the design F-Engrave will look for uncut material. Any material that needs to be cut during the cleanup operation should be less than this distance away from the design. This larger this setting is the longer the calculation will take.

8b. Enter the cleanup cut data:

**Cleanup Cut Diameter**: Diameter of the cleanup bit to be used. (typically a straight flat nosed bit) **Cleanup Cut Step Over**: Step over distance for the cleanup cuts. Entered as a percentage of the bit diameter **Cleanup Cut Directions**: The cut direction to use for the cleanup bit, "X" lines in the x-direction, "Y" lines in the y-direction, "P" cut the perimeter of the uncut area.

8c. Enter the v-bit cleanup cut data:

V-bit cleanup is cutting the tight corners that the cleanup bit can not reach. The v-bit specified for v-carving is used for this operation.

Cleanup Cut Step Over: Step over distance for the cleanup cuts. Entered as a distance.

**Cleanup Cut Directions**: The cut direction to use for the v-bit cleanup, "X" lines in the x-direction, "Y" lines in the y-direction, "P" cut the perimeter of the uncut area.

V-Bit Angle	60	deg						
V-Bit Diameter	.25	in						
Max Cut Depth	-0.217	in Diameter						
Inside Corner Angle (Less Than)	135	deg V-Bit Angle						
Outside Corner Angle (Greater Than)	200	deg						
Sub-Step Length	0.01	in						
Check all or Current Char Only	© All	C Character only						
Flip Normals (V-Carve Side)								
Plot During V-Carve Calculation	~							
Cleanup Operations								
Cleanup Search Distance	1	in 8a. Calculate						
Cleanup Cut Diameter	.125	Cleanup	$\backslash$					
Cleanup Cut Step Over	50	% 8b.						
Cleanup Cut Directions	P V	X X G-Code	98					
V-Bit Cleanup Step	.02	in a ver						
V-Bit Cut Directions	ПРГ	X V Y	/					
Calculate V-Ca	arve	Close						

# Step 9. Clean Up Execution and Save

9a. The cleanup calculation can now be executed using the **Calculate Cleanup** button on the v-carve settings window. The first time this button is pressed after a v-carve operation the cleanup areas are calculated. The areas are saved and reused until the **Cleanup Search Distance** is changed or the **Calculate V-Carve** button is press again. After the cleanup calculations are complete the display will be updated. The cleanup cut area will be plotted as reddish/brown areas with white tool path lines and the v-bit tool path will be plotted as yellow lines.

The cleanup g-code and the v-bit cleanup g-code can now be saved using the buttons on the v-carve settings window. Each of the two cleanup operations should be saved to separate files. (Don't forget to save the v-carving g-code file from the main window file menu)

The saved g-code files can now be run on a CNC machine. The output from F-Engrave is compatible with LinuxCNC and Mach3.

f-engrave-0.9.p	y by Scorch	1				
File Edit View	Settings	Help				
Image Properties	:		A			
Image Height	5	in				
Line Thickness	0.01	in				
Image Width	100	%				
Image Position a	nd Orientat	ion:				
Image Angle	0.0	deg				
Origin	Defaul	t 💷				
Flip Image						
Mirror Image						
Gcode Properties	:					
Feed Rate	50	in/min				
Z Safe	.04	in				
Cut Depth	-0.005	in				
Polski_Crest.bmp	,					
	C Engra	ive				
	V-Car	ve				
Recalculate	Calc V-	Carve				
File Saved: Z:/Polski_Crest_v_clean.ngc						

# Extra Credit

To make the second carving shown at the beginning of this document two settings need to be adjusted. First the normals of the image need to be flipped (in the v-carve settings window). This changes the side of the image that gets carved so that the white gets carve instead of the black in the image. Second a bounding box is added to the image to limit the amount of material that is removed around the image (in the general settings window). A screenshot after all of the calculations are performed for this case is shown below (next page). See if you can do similar with your image.

V-Carve Settings							
V-B	it Angle	60	deg	$\frown$			
V-Bit	.25	in	V-Bit				
Max C	Cut Depth	-0.217	in	Diameter			
Inside Corner	Angle (Less Than)	135	deg	V-Bit Angle			
Outside Corner A	Angle (Greater Thai	n) 200	deg				
Sub-St	ep Length	0.01	in				
Check all or C	Current Char Only	Θ Δ11	c	Character only			
Flip Normal	s (V-Carve Side)		>	character only			
Plot During V-	Carve Calculation						
-							
Settings							
Units	inch	C mm					
X Offset	0.0 in	~					
Y Offset	0.0 in						
Arc Angle	10.0 deg						
Accuracy	0.001 in						
Enable Arc Fitting	$\overline{\mathbf{v}}$						
G Code Header G17 G90 G64 M3 S3000 M7							
G Code Postscript M5 M9 M2							
Font Directory fonts Select Dir							
Height Calculation @ Max Used © Max All							
Add Box/Circle O No O Yes Box/Circle Gap: .5 in							
R	ecalculate	Re-Load Imag	le	Close			



# Additional notes

Looking closely at the images on the first page reveals that some detail is missing from the carving. In the left image detail is missing from the eagles face. The image on the right is clearly missing detail from the eagles feet. The g-code output included these details but the v-bit used to carve the images did not come to a true point. The diameter of the tip is 0.040 inches so any features less than 0.040 inches in the output design will be lost because the bit is cutting air.

Good Luck! Scorch

**F-Engrave Home**